Parts Price List

For

DeVRY 35 mm. MOTION PICTURE SOUND EQUIPMENT

Type "D" Model "2812" - "2804" - "1100"

Type "C" Model "10" - "7" - "1975"

Minimum Net Order $1.00

Parts in this price list are identified in either the DeVry Type "D" or Type "C" Instruction Manual and Parts Catalog

DE VRY CORPORATION
1111 Armitage Avenue **Chicago, Illinois**

BRANCH OFFICES
NEW YORK HOLLYWOOD

Distributors in Principal Cities of the World

Part No.	Description	Price
35	ROLLER, (OFA), film, ASSEMBLY	$ 2.00
44(D)	CORD, projector-amplifier-power, ASSEMBLY	16.00
46	ROLLER, film guide ASSEMBLY	4.00
86	SPRING, friction	.10
89(D)	BLOCK, tilting bracket slide	.75
95(D)	SCREW, tilting bracket lock	1.50
97(D)	PAD, rubber	.25
108	CLEAT, single steel	.05
110	CLEAT, double steel	.05
111	SPRING, sprocket	.10
135	SPACER	.10
215	SPACER, idler arm stop	.10
235	SPROCKET, intermittent film	8.00
242(D)	PLUG, female twist lock projector	2.10
243(D)	RECEPTACLE, male twist lock	1.50
260(D)	SPACER, terminal strip	.15
291	WASHER, split lock No. 6	.05
292	WASHER, split lock No. 8	.05
293	WASHER, split lock No. 10	.05
294	WASHER, ¼" split lock	.05
295	WASHER, split lock 5/16"	.05
296(D)	WASHER, inner cut lock, 1⅛" O.D., 11/16" I.D.	.05
366	PIN, dowel	.10
399	LAMP, 1 amp. 6 olt T-5 prefocused exciter	.85
400	LAMP, 6-8 volt bayonet base	.15
411	LAMP, 10 watt, 115 volt S-11 Pilot	.25
413	LAMP, framing	.30
415	LAMP, 6 watt 110-120 volt	.50
479(D)	LAMP, 1000 watt, 115 volt T-20 prefocused	4.50
499(D)	CONDENSER, prismatic	1.25
537	SHAFT, roller	.15
553	SPRING	.10
580	REEL, 1000' 35 mm.	.90
583(D)	REFLECTOR	1.50
587(D)	CONDENSER, plain	1.50
602	LINK, fire-shutter	.05
621	SPROCKET, (517A), holdback	7.00
641	GROMMET, rubber 7/16" O.D. x ¼" I.D.	.10
673	SCREW, fillister head 8-32 x 7/16"	.05
684	SCREW, fillister head 10-32 x ½"	.05
685	SCREW, fillister head 8-32 x ½"	.05
687	SCREW, round head 5-40 x ½"	.05
691	PIN, taper	.05
695(D)	LUG, solder	.05
698(D)	LUG, solder	.05
699	SCREW, round head 2-56 x ¼"	.05
700	SCREW, fillister head 10-32 x ⅞"	.05
701	SCREW, fillister head 10-32 x 1⅛"	.05
709(D)	SCREW, binder head 6-32 x ¼"	.05
712	SCREW, headless set	.05
718	SCREW, flat head 5-40 x ¾"	.05
721(D)	SCREW, set 10-32 x ¼"	.05
722	SCREW, set 6-32 x ⅛"	.05
724	SCREW, set 8-32 x ⅜"	.05
730	SCREW, round head 5-40 x 1⅛"	.05
735(D)	WASHER, inner cut lock ¼" O.D. No. 6	.05
736(D)	WASHER, inner cut lock 11-16" O.D. x ⅜" I.D.	.05
740	SCREW, round head 5-40 x ⅛"	.05
741	SCREW, flat head 10-32 x ⅜"	.05
745	SCREW, set, ¼"—20 x 5/16"	.05
748	WASHER, #10 inner cut lock ⅜" O.D.	.05
751	WASHER, steel ½" O.D. x ⅛" I.D.	.05
753	WASHER, steel ¾" O.D. x 5/16" I.D.	.05
756(D)	SCREW, flat head 10-32 x ¾"	.05
760(D)	PIN, drive	.05
786	SCREW, flathead 5-40 x 5/16"	.05
795(D)	SCREW, fillister head, 10-32 x ⅜"	.05
797	WASHER, inner cut lock 5/16" O.D. No. 8	.05
799	SCREW, round head 8-32 x ¼"	.05
802	SCREW, round head 8-32 x 5/16"	.05
803	SCREW, round head 8-32 x ⅜"	.05
806(D)	SCREW, round head 6-32 x 5/16"	.05
807	SCREW, round head 6-32 x 3/16"	.05
808	SCREW, round head 6-32 x ¼"	.05
809(D)	SCREW, round head 6-32 x ⅝"	.05
810(D)	SCREW, round head 6-32 x ¾"	.05
811(D)	SCREW, round head 6-32 x 1½"	.05
813	SCREW, round head 6-32 x ⅜"	.05
821(C)	SCREW, flat head, 8-32 x 9/16"	.05
829	SCREW, fillister head 3-48 x ⅛"	.05
830	SCREW, round head 3-48 x 3/16"	.05
831	SCREW, fillister head 10-32 x 7/16"	.05
832	SCREW, round head 5-40 x 5/16"	.05
836	SCREW, round head 5-40 x 3/16"	.05
838	SCREW, round head 5-40 x ⅜"	.05
841	SCREW, set 5/32-40 x 3/16"	.05
843	SCREW, fillister head 10-32 x ¾"	.05

Part No.	Description	Price
845	SCREW, round head 3-48 x ⅛"	.05
851(D)	SCREW, fillister head 8-32 x ¾"	.05
852	SCREW, flat head 2-56 x ⅛"	.05
853	SCREW, round head 5-40 x ¼"	.05
858	SCREW, flat head 8-32 x ⅜"	.05
860	SCREW, flat head 8-32 x ½"	.05
864(D)	SCREW, flat head 8-32 x ⅝"	.10
867(D)	SCREW, flat head 8-32 x 1¼"	.05
868	SCREW, fillister head 10-32 x ⅝"	.05
871	SCREW, Allen set 10-32 x 3/16"	.05
877	SCREW, fillister head 8-32 x ⅝"	.05
881	SCREW, fillister head 8-32 x ⅜"	.05
883	WASHER, 9/16" O.D. x 5/16" I.D. steel	.05
890	BOLT, hexagonal head 5/16-18 x 1¼"	.05
892(D)	WASHER, inner cut lock ¾" O.D. x ½" I.D.	.05
893(D)	BOLT, round head 4½" with 10-24 square nut	.10
898	WASHER, steel 5/16" O.D. x ⅛" I.D.	.05
912(C)	SCREW, 8-32 x 9/16" Fillister head	.05
916	SCREW, round head 5-40 x ⅝"	.05
919	SCREW, flat head 2-56 x 5/16"	.05
922	SCREW, round head 2-56 x 3/16"	.05
923	SCREW, fillister head 2-56 x ⅝"	.05
926	SCREW, fillister head 2-56 x ⅛"	.05
947	SCREW, fillister head 5-40 x 3/16"	.05
960	WASHER, brass ⅜" O.D. x ⅛" I.D.	.05
965	WASHER, steel ½" O.D. x 5/16" I.D.	.05
966(D)	WASHER, case, 8-32 #8	.05
967	WASHER, steel ⅜" O.D. x ⅛" I.D.	.05
968	WASHER, steel ½" O.D. x 5/32" I.D.	.05
976	PIN, taper	.10
977	PIN, taper	.10
978	PIN, name plate	.05
979	PIN, Escutcheon, ⅜" x 14	.05
981	NUT, hexagonal 6-32	.05
982	NUT, hexagonal 8-32	.05
983	PIN, name plate	.05
987	NUT, hexagonal 2-56	.05
990	SCREW, fillister head 3-48 x 5/16"	.05
991	WASHER, fiber ½" O.D. x ¼" I.D.	.05
992	WASHER, steel ⅝" O.D. x ¼" I.D.	.05
994	NUT, hexagonal ¼"-20	.05
995	RIVET, weight	.05
996	NUT, hexagonal 10-32	.05
999	BOLT, hexagonal head ¼"-20 x ⅞"	.05
1005(D)	MOTOR, ventilating, ASSEMBLY	14.15
1010(D)	CONDENSER ASSEMBLY	7.00
1033	FLANGE, large spring	.15
1039	SPRING, aperture shoe	.10
1041	SCREW, yoke retaining	.15
1045	NUT, tension adjustment	.30
1047	SCREW, tension lock	.35
1049	ROLLER, small fire	1.50
1050	ROLLER, large fire	2.10
1051	PLATE, small roller	.55
1052	PLATE, large roller	.85
1072(D)	MOTOR, ventilating	10.25
1075	ROD, lapping 7/16"	1.00
1076	ROD, lapping 5/16"	1.00
1077	ROD, lapping ¼"	1.00
1078	BLOCK, v-support	2.25
1092	BROACH, taper-pin	1.75
1093	POWDER, bottle lapping	.20
1094	BRUSH, cleaning ¼"	.25
1095	BRUSH, cleaning 5/16"	.25
1096	BRUSH, cleaning 7/16"	.25
1097	ADAPTOR, lens, for Series I lens only	11.25
1100(D)	SPEAKER, loud, and case ASSEMBLY	60.00
1105	SPRING, tension	.25
1114	SCREW, knurled	.35
1134	PLATE, mechanism drilled mounting	30.00
1142	SLEEVE, housing	14.70
1143	RAIL, aperture film	6.00
1146	BEARING, ball	1.25
1149	GLASS, picture framing	.10
1151(D)	SOCKET, prefocus lamp	2.45
1154	SPRING	.10
1163(C)	BRACKET, stud tilting	.75
1164(C)	SCREW, tilting	7.00
1165(C)	BRACKET, tilting	3.50
1166(C)	KNOB, tilting	10.00
1167(D)	INSULATOR, baffle plate	.05
1169(D)	SPACER, condenser	1.00
1170(D)	RETAINER, wire ring	.35
1182(D)	HOUSING, condenser	.85
1183	CASTING, lower fire roller	2.50
1184	YOKE, tension, SUB-ASSEMBLY	1.00
1185	PLATE, film gate mounting, SUB-ASSEMBLY	8.00

Part No.	Description	Price
1188(C)	PLATE, tilting sector wing	1.60
1190(D)	NUT, hexagonal 6-32	.05
1194	GLASS, door	.50
1196	SPROCKET & bearing SUB-ASSEMBLY	5.25
1215	MOUNT, pilot lamp socket	.45
1216	SOCKET, pilot lamp	1.65
1221	RETAINER, door glass	.05
1236	PLATE, stripper	.25
1243	ROLLER, sound adjustment	4.50
1244	SHAFT, sound adjustment roller	2.75
1245	NUT, tension adjustment	.70
1246	NUT, lock	.90
1304	SPROCKET, motor chain	4.00
1307	BEARING, ball	1.00
1325	SHAFT, sprocket	1.30
1326	BLOCK, mounting	5.00
1327(C)	BRACKET, door latch	2.00
1328	WASHER, micarta	.15
1329	LATCH, door	2.25
1330	PIN, door latch	.10
1332	CAP, spring	.30
1333	SPRING, door latch	.10
1334(C)	CATCH, door latch	1.00
1336	NUT, tension lock	.75
1339	HOUSING, ball bearing	4.50
1343	FLANGE, small spring	.30
1346	NUT, tension adjustment	.55
1348	SPRING, idler lock	.05
1349	SCREW, retainnig	.10
1354	KNOB, idler	.50
1355	NUT, idler lock	.15
1356	ROD, idler lock	.10
1358	ROLLER, inner idler	.45
1359	ROLLER, outer idler	.65
1368	BEARING, ball	2.00
1376	KNOB, focusing	1.35
1377	SCREW, thumb	.40
1379	FLANGE, bracket	7.00
1396	PLATE, baffle mounting	.85
1398(D)	PLATE, aperture baffle SUB ASSEMBLY	2.60
1427	TUBE, knurled	5.65
1429	SHOE, upper film	1.50
1431	SPRING, film shoe	.15
1448	BRACKET, film gate	3.15
1450	TAKEUP ASSEMBLY	45.10
1451	STUD, eccentric pivot	.60
1456	SCREW, fillister head 1/4"-20 x 3/4"	.05
1458	ROLLER, chain idler	.90
1459	SCREW, fillister head 1/4-20 x 1/2"	.05
1462	COLLAR	.40
1464	COVER, ball bearing	.20
1466	WHEEL, friction plunger	6.00
1467	HOUSING, bearing	7.50
1468	CYLINDER, friction take-up	9.00
1469	SLEEVE, bearing	2.75
1472	ARM, release pivot	.75
1516	SCREW, film gate lock	1.25
1521	WASHER, steel, 1/2" O.D. x 3/16" I.D.	.05
1525	BEARING, ball	2.00
1532	KNOB, motor	2.40
1534	SPROCKET, takeup chain	2.80
1535	STUD, roller	.35
1544	GLASS, door	1.25
1556	NUT, aperture roller adjustment	.35
1560(C)	BASE, projector mounting, ASSEMBLY	200.00
1561(C)	BASE, projector mounting	50.00
1563(C)	SHAFT, tilting sector pivot	1.50
1564(C)	BOLT, tilting sector	3.00
1565(C)	PIN, tilting sector bolt	.30
1566(C)	NUT, tliting sector	2.50
1568(C)	SECTOR, tilting	8.50
1593	STUD, film shoe	.25
1601(D)	LENS, Series I ASSEMBLY	47.50
1602	MOTOR, drive, ASSEMBLY	56.85
1604(C)	MAGAZINE, feed, ASSEMBLY	83.00
1618(D)	CEMENT, pint can film	2.50
1640	REWIND, 35mm 2000' bench	14.00
1680	BAFFLE, low frequency	120.00
1685(C)	CASE, upper, ASSEMBLY	150.00
1688(C)	MAGAZINE, feed, SUB-ASSEMBLY	67.00
1695(C)	CASE, lower, ASSEMBLY	150.00
1709	TUBE, rectifier, 15 amp.	10.00
1740(D)	BOX, tool and spare parts	22.50
1792(D)	CORD, and plug SUB-ASSEMBLY	2.50
1809	SPLICER, 35mm.	25.50
1812	SPLICER	9.00
1848(C)	RECTIFIER, D.C. exciter lamp, ASSEMBLY	50.00

Part No.	Description	Price
1851(D)	HANDLE, speaker baffle	1.35
1852(D)	HANDLE	1.25
1853(D)	CUSHION, case	.10
1889	OIL, quart can intermittent	1.25
1892	HANDLE, door, ASSEMBLY	2.25
1921(C)	CONE & VOICE COIL ASSEMBLY	10.00
1922(C)	DIAPHRAGM	20.00
1984(D)	RIVET, 5/32"	.05
1985(D)	RIVET, 3/16"	.05
2016(C)	TRANSFORMER, power (Code T9)	35.00
2017(C)	CHOKE, (Code T8)	15.00
2019(C)	HORN, high frequency	112.50
2020(C)	DRIVER-UNIT, high frequency	178.00
2021(C)	SPEAKER, low frequency	80.00
2022(C)	NETWORK, speaker (Code T7) ASSEMBLY—Complete	104.50
2023(C)	FIELD SUPPLY, ASSEMBLY	93.75
2024(C)	TRANSFORMER, (Code T10)	18.00
2103	PLATE, photo-cell name	.10
2104	PLATE, 110 volt name	.15
2105(D)	PLATE, amplifier dial	1.50
2106	PLATE, exciter and pilot name	.20
2107	NUT, knurled mounting	1.60
2108	SPRING, sound lens	.15
2114	CHAIN, shutter driving, 56 link	7.65
2121	CHAIN, feed and intermittent driving, 101-link	11.10
2122	CHAIN, sound driving, 68-link	7.40
2123	CHAIN, take-up driving, 76-link	8.25
2134	COVER, exciter lamp, SUB-ASSEMBLY	5.50
2138(C)	BRACKET, chase nipple	1.00
2139(C)	NIPPLE, 1" chase	.50
2140	NUT, knurled cover	.30
2141	STUD, cover mounting	.50
2142	SPRING, plunger	.05
2143	PLUNGER, friction	.15
2150(C)	SWITCH, changeover foot ASSEMBLY	21.00
2151	TIP, rawhide friction	.10
2152	RING, intermittent	.05
2166(C)	CHANGEOVER, sound and picture ASSEMBLY	71.00
2168(C)	BRACKET, changeover mounting	5.60
2169(C)	SLIDE, changeover cut-off	7.15
2170(D)	SOCKET, projection lamp, ASSEMBLY	2.75
2175	WEIGHT, governor, KIT ASSEMBLY	.25
2190	STUD, idler KIT ASSEMBLY	2.30
2191	SPROCKET, film sound	6.00
2192	SPROCKET, feed, SUB-ASSEMBLY	31.00
2193	IDLER, sound driving chain, ASSEMBLY	4.25
2194(C)	CABLE, photo cell	9.00
2200(D)	BAFFLE, lamp	1.75
2201(D)	SLIDE, lamphouse mounting	.70
2202(D)	SUPPORT, lamp yoke	2.00
2210(D)	FAN, blower wheel	2.50
2213	SPROCKET, feed-chain	8.80
2216	SPROCKET, feed, ASSEMBLY	39.00
2217	SPROCKET, film feed	6.00
2220	SPROCKET, sound ASSEMBLY	33.50
2223	SPROCKET, sound chain, SUB-ASSEMBLY	5.60
2224	SPROCKET, feed chain, SUB-ASSEMBLY	7.50
2225	WASHER, steel 5/8" O.D. x 5/32" I.D.	.05
2226	SPRING, sprocket shoe	.10
2228	SHOE, intermittent sprocket	5.75
2230	GATE, film, ASSEMBLY	32.75
2233	SHOE, lower film	1.50
2250	APERTURE, silent, ASSEMBLY	1.20
2252	APERTURE, sound, ASSEMBLY	1.40
2253	MOUNT, lens	13.75
2254	BLOCK, idler mounting	1.85
2255	SCREW, shoulder	.25
2258	LEVER SUB-ASSEMBLY	1.25
2259	IDLER, take-up driving chain ASSEMBLY	4.50
2260	SPROCKET, intermittent chain	4.50
2268	STUD, upper framer gear	.60
2269	WASHER, framer chain idler	.15
2270	STUD, center, chain idler framer	.85
2272	SCREW, framer gear	.35
2273	HOUSING, intermittent	10.00
2274	HEAD, framer gear	6.50
2275	GEAR, framer	2.50
2276	COLLAR, framer shaft	.30
2277	SHAFT, framer	1.00
2278	GEAR, framer shaft	2.00
2280	MOVEMENT, intermittent SUB-ASSEMBLY	115.00
2282	BEARING, chain idler	1.75
2283	COVER, rear exciter lamp	.25
2284	BLOCK, idler mounting	1.50
2287	FLYWHEEL, sound drum	20.00
2289	SCREW, flywheel	.80

MINIMUM NET ORDER $1.00

Part No.	Description	Price
2290	FILTER, sound, ASSEMBLY	62.80
2293	BEARING, ball	2.15
2299	CLIP, metal	.05
2300(D)	CLAMP, lamp socket, SUB-ASSEMBLY	1.25
2302	STUD, chain idler	2.20
2305	IDLER, feed and intermittent chain ASSEMBLY	7.50
2307	COVER, photo cell	2.25
2308	BRACKET, photo-cell	2.50
2310(C)	COVER, metal	3.50
2311	SOCKET, photo-cell with lock ring	.20
2313	MOUNT, photo-cell ASSEMBLY	13.50
2315	BRACKET, shutter	9.50
2318	SHUTTER, fire	.65
2319	LEVER, fire shutter	1.20
2322	SCREW, fire shutter lever	.25
2323	CAP, shutter housing	.15
2326	SHAFT, shutter drive	6.25
2329	GOVERNOR, fire shutter	5.00
2330	SHUTTER ASSEMBLY	70.85
2332	SCREW, fire shutter	.20
2333	BRACKET, exciter lamp	3.50
2334	NUT, sound lens	.60
2335	COVER, exciter lamp	4.50
2336	RUBY, glass	.25
2340	LAMP, exciter, KIT ASSEMBLY	45.00
2343	BRACKET, idler	1.50
2344	SPRING, idler	.10
2345	SHAFT, floating idler	.65
2349	ROLLER, stationary idler	2.65
2350	IDLER, floating film, ASSEMBLY	12.75
2351	ROLLER, floating idler	2.25
2356	KNOB, frame	.65
2361	DRUM, sound, SUB-ASSEMBLY	23.50
2363	CUP, oil	.20
2366(D)	BRACKET, speaker cable	.35
2367	OILER ASSEMBLY	1.60
2368	SCREW, shutter drive gear lock, left hand	.20
2370	PULLEY, adjustment	1.40
2371	ROLLER, shutter driving chain idler SUB-ASSEMBLY	2.35
2372	BLADE, shutter, SUB-ASSEMBLY	6.25
2375	SCREW, extension adjustment	.35
2378	MOTOR, flywheel, ASSEMBLY	9.50
2379	MOUNT, lens, ASSEMBLY	35.00
2380	SPROCKET, hold-back, ASSEMBLY	24.00
2385	BRACKET, roller, SUB-ASSEMBLY	1.20
2390	IDLER, sprocket, SUB-ASSEMBLY	6.00
2393	SHAFT, feed, SUB-ASSEMBLY	16.50
2394	ROLLER, sound adjustment, ASSEMBLY	9.50
2396(C)	VALVE, lower fire ASSEMBLY	8.50
2404(D)	PLATE, aperture, ASSEMBLY	43.00
2405(D)	LUG, solder	.05
2416	SCREW, bristo-set 5/40 x 1/8"	.05
2420	MOUNTING, film gate, ASSEMBLY	6.00
2421	RELEASE, film gate ASSEMBLY	6.55
2429	ADAPTOR, take-up	3.75
2430	SCREW, special shoulder fire guard	.20
2439(C)	SCREW, projector base mounting	.60
2459	CABLE, photo-cell, rubber covered	1.75
2460(D)	CABLE, 18" shielded	.75
2607	SHIELD, threading lamp wire flexible	.50
2609	SHIELD, framing lamp wire flexible	.35
2620(D)	WIRE, black solid push back ft.	.02
2621(D)	WIRE, yellow solid push back ft.	.03
2622(D)	WIRE, yellow No. 20 stranded hookup ft.	.02
2623(D)	WIRE, black No. 20 stranded hookup ft.	.02
2624(D)	WIRE, blue No. 20 stranded hookup ft.	.02
2625(D)	WIRE, brown No. 20 stranded hookup ft.	.02
2626(D)	WIRE, green No. 20 stranded hookup ft.	.02
2627(D)	WIRE, maroon No. 20 stranded hookup ft.	.02
2628(D)	WIRE, orange No. 20 stranded hookup ft.	.02
2629(D)	WIRE, red No. 20 stranded hookup ft.	.02
2630(D)	WIRE, yellow and black tracer stranded hookup ft.	.02
2680(D)	CORD, 10' of No. 2689	.85
2681(D)	CORD, 100' of No. 2689	8.75
2691(D)	CORD, 25' rubber covered projector	5.25
2692(D)	WIRE, shielded grid ft.	.04
2705(D)	WIRE, spaghetti No. 9 flexible varnished tubing ft.	.07
2900(C)	PRE-AMPLIFIER, complete ASSEMBLY	65.00
3077(D)	CABLE (5 ft. required) ft.	.21
3083(D)	SCREW, contact	.35
3084(D)	BUSHING, front threaded fiber	.20
3085(D)	BUSHING, rear plain fiber	.25
3091(D)	CABLE, projector & amplifier sound, SUB-ASSEMBLY	15.60

Part No.	Description	Price
3092(D)	SHELL, socket	.50
3093(D)	BUSHING, socket	.10
3121	STUD, fire shutter lifting	.15
3126(D)	PLUG, P.E. ASSEMBLY (for service)	3.25
3142(D)	CLAMP, P. E. cable wire	.35
3143(D)	CLAMP, shield ground	.25
3145	GUARD, aperture fire	.40
3335	SCREW, side tension adjustment	.50
3338	ROLLER, plain side tension	2.50
3339	ROLLER, tapped side tension	3.00
3340	SHAFT, side tension roller	.50
3345	SPRING, side tension roller	.10
3355(C)	PLATE, aperture, ASSEMBLY	52.50
3368	APERTURE, film shoe KIT ASSEMBLY	6.00
3370	WIRE, pilot lamp 76"	.30
3371	WIRE, framing lamp 64"	.35
3372(D)	WIRE, 14 gauge No. 200 4 ft.	.35
3373(D)	WIRE, 16 gauge No. 201 8 ft.	.55
3607	IDLER, holdback sprocket, SUB-ASSEMBLY	6.25
3713	ROD, film gate slide	.35
3747(C)	TRANSFORMER, output (Code T5)	2.40
3761(D)	CHASSIS, amplifier	15.00
3765(D)	BAFFLE, 3 tube heat	3.00
3766(D)	STUD, knob guard	.75
3768(D)	GUARD, knob SUB-ASSEMBLY	2.00
3774(D)	PANEL, amplifier front	4.00
3775(D)	CASE, amplifier chassis	18.50
3800(C)	COIL, A.C. changeover (with female connector)	18.75
3806(D)	CORD & plug SUB-ASSEMBLY	16.50
3807(C)	CONDENSER, 3000-3000 mfd. 20 working volt	8.00
3810(C)	CHASSIS, exciter lamp rectifier	2.50
3811(C)	RECEPTACLE, 4 pin female	.20
3812(C)	CONDENSER, .04 mfd. 600 volt (Code C24)	.15
3813(C)	CONDENSER, .03 mfd. 600 volt (Code C1, C6)	.15
3814	CONDENSER, 19-19 mfd. 575 volt	4.50
3815(D)	CONTROL, 9 megohm bass	1.00
3816(D)	CONTROL, 50,000 ohm treble	.60
3817	RESISTOR, 1000 ohm, 25 watt	.60
3818	RESISTOR, 200 ohm, 50 watt variable	1.50
3819(D)	RESISTOR, 2500 ohm, 50 watt	.85
3821	TRANSFORMER, power	10.55
3823	CHOKE	3.70
3824	TRANSFORMER, input	10.00
3826	CONDENSER, .002 mfd. 600 volt	.30
3827	CONTROL, 250,000 ohm volume	.60
3828	SOCKET, 5 U 4 tube (Code P5)	.30
3831(D)	GROMMET, 5/16" O.D. x 5/32" I.D.	.05
3835(C)	CONDENSER, .001 mfd. 600 volt (Code C13, C15)	.30
3836(D)	CONDENSER, .01 mfd. 600 volt	.30
3837(C)	TRANSFORMER, line to line (Code T6)	30.00
3841(D)	STRIP, 5 contact terminal	.15
3842	STRIP, 8 contact terminal	.15
3844(C)	RESISTOR, 5000 ohm, ½ watt (Code R4, R16, R31)	.15
3847(D)	RESISTOR, 1000 ohm ½ watt	.15
3851	RESISTOR, 75,000 ohm ½ watt	.25
3854	FERRULE, flexible shield	.10
3855(D)	STRIP, 6 contact terminal	.50
3859(D)	CONDENSER, .00025 mfd.	.15
3860(D)	CASE, Speaker with hardware	31.50
3861	CONDENSER, .1 mfd. 600 volt	.20
3862	CONDENSER, .05 mfd. 600 volt	.20
3863	CONDENSER, 10-10-10 mfd. 450 volt	1.25
3867(C)	CHOKE	4.15
3872(C)	ELEMENT, selenium rectifier	10.00
3874(C)	STRIP, 6 lug terminal (Code A2)	1.50
3875(C)	STRIP, 12 lug terminal	1.50
3882	SOCKET, 6 L 6 tube	.30
3899(D)	CONE & voice coil ASSEMBLY	5.75
3900(D)	GROMMET, ¼" O.D. x ⅛" I.D.	.05
3914(D)	KNOB, red control	.25
3935	RECEPTACLE, pilot lamp	.35
3937(D)	RECEPTACLE, male twist lock power	.90
3940(D)	PLUG, female twist lock amplifier	1.00
3952	PLATE, DeVry name	.35
3964	RECEPTACLE, fuse	.45
3981	TRANSFORMER, output	6.25
4008(C)	PLUG, 4 pin male	.50
4013(C)	RESISTOR, 2000 ohm, 1 watt (Code R25)	.15
4016(D)	RESISTOR, 10,000 ohm 1 watt	.20
4018(C)	RESISTOR, 250,000 ohm 1 watt (Code R14)	.25
4020(C)	RESISTOR, 1 meg ohm ½ watt (Code R8)	.10
4024(D)	RESISTOR, 1.5 megohm ½ watt	.15
4026	RESISTOR, 20,000 ohm 1 watt	.25
4027(C)	RESISTOR, 1000 ohm, 2 watt (Code R7, R32)	.35
4029	RESISTOR, 2500 ohm ½ watt	.15

Part No.	Description	Price
4031	SOCKET, 6 J 7 tube	.30
4037(C)	RESISTOR, 150,000 ohm, ½ watt (R17, R18)	.10
4038(C)	RESISTOR, 3000 ohm, ½ watt	.10
4042(C)	POTENTIOMETER, 25,000 ohm (Code R5) (Code R20)	.60
4051(C)	CONDENSER, .1 mfd. 400 volt	1.00
4053	CONDENSER, .005 mfd. 600 volt	.60
4063(C)	FUSE, 2 ampere	.06
4096(D)	CLIP, tube-grid	.05
4080(C)	RESISTOR, 7500 ohm, 25 watt (Code R29)	.70
4081(D)	RECEPTACLE, 4 pin speaker	1.20
4082(D)	PLUG, male 4 pin	1.25
4085	FUSE, 3 ampere	.06
4086(D)	CLIP, fuse	.05
4096(D)	CLIP, tube-grid	.05
4119(C)	BRACKET, resistor mounting	.15
4121	SOCKET, 6 N 7 tube	.30
4124(D)	SCREEN, speaker	3.00
4126	CONDENSER, .02 mfd. 400 volt	.15
4133	EYELET, contact	.05
4138(D)	Plate, microphone input name	.15
4139(D)	PLATE, phonograph input name	.15
4152(D)	PLUG, 2 prong male, power	.20
4157	CONDENSER, 10 mfd. 25 volt	.50
4158(C)	ATTENTUATOR, 250,000 ohm (Code R10)	18.00
4159(D)	SPEAKER	43.50
4175	CLEAT, fiber	.05
4180(D)	CASE, amplifier chassis, ASSEMBLY	24.00
4184	SOCKET, 6SF5 tube	.30
4186(D)	TRANSFORMER, exciter lamp	2.25
4188(C)	SPEAKER, PM-8-6 (Code B1)	11.00
4197	RESISTOR, 500,000 ohm ½ watt	.15
4198	RESISTOR, 100,000 ohm ½ watt	.15
4199	WASHER, steel ⅝" O.D. x ⅜ I.D.	.05
4200(D)	NUT, ⅜" hexagon	.05
4205	RESISTOR, 250,000 ohm ½ watt	.15
4208(C)	CONDENSER, 8-8-8 mfd. 450 volt (Code C21, C22, C23)	1.35
4211(C)	SWITCH, 3 gang, 7 tap, with plate (Code S1)	3.75
4212(C)	SWITCH, single gang, 5 point tap, with plate (Code S2)	1.40
4213(C)	RESISTOR, 10 ohm, 5 watt (Code R27)	.40
4230(C)	SOCKET, 6 F 6 tube (Code P3, P7)	.10
4234(C)	RESISTOR, 25,000 ohm 1 watt (Code R12, R13)	.10
4235(C)	CONDENSER, .0005 mfd. 500 volt (Code C17)	.30
4240	PLATE, motor & lamp switch name	.50
4242(C)	TRANSFORMER, rectifier power	6.00
4246(C)	CONDENSER, .004 mfd. 400 volt (Code C14)	.35
4259(C)	ELEMENT, micro switch	5.00
4261(C)	SWITCH, micro	5.65
4266	CAP, tube shielding	.15
4271(D)	STRIP, resistor, ASSEMBLY	7.65
4278(C)	RESISTOR, 25,000 ohm ½ watt (Code R15)	.15
4280	RECEPTACLE, male 4 pin projector sound	2.50
4281	PLUG, female 4 conductor	2.55
4301	TUBE, 6 J 7 amplifier	1.80
4305(C)	TUBE, 5 Z 3 (Code V8)	1.50
4306	TUBE, 6 N 7 G	2.20
4310	TUBE, 5 U 4 G (Code V5)	1.35
4311(C)	TUBE, 6 F 6 (Code V3, V7)	1.50
4325	TUBE, 5 X 4 G	1.50
4327	TUBE, 6 L 6 G amplifier	2.65
4362	TUBE, 6 S F 5 amplifier	1.35
4410	LENS, sound	18.50
4453	CELL, photo-electric CE 25	6.00
4489(D)	STRIP, resistor, SUB-ASSEMBLY	2.60
4519	SWITCH, threading or exciter lamp	.60
4523(D)	COVER, speaker-cable terminal	.80
4526(D)	SHIELD, sound input receptacle	1.05
4533(C)	CONDENSER, 25 mfd. 50 volt (Code C25)	.60
4539(C)	FUSE, one ampere 3-A-6	.06
4551(D)	GROMMET, rubber ½" O.D. x ⅜" I.D.	.05
4553(C)	RECEPTACLE, pilot lamp, green screw base ASSEMBLY	1.40
4569(D)	JACK, microphone-turntable input	.15
4576(C)	SOCKET, 5 Z 3 tube (Code P9)	.15
4599(D)	RECEPTACLE, sound input	1.00
5133	WASHER, steel 9/16" O.D. x 7/64" I.D.	.05
5153	WASHER, fiber ⅝" O.D. x ⅜" I.D.	.05
5183	STUD, idler	.20
5220	SCREW, binder head 8-32 x 5/16"	.05
5222	SCREW, binder head 5-40 x 3/16"	.05
5233	PLATE, DeVry name	.35
5669	WASHER, steel ⅜" O.D. x ¼" I.D.	.05
5712(D)	SCREW, 8-32 steel thumb	.55
5819	REEL, steel 35 mm. 2000'	2.25
6493	LENS, coated 4" series I, projection	36.25

Part No.	Description	Price
7021(D)	BRACKET, motor	1.25
7076	SCREW, knurled tube	.10
7103	LOCK, reel	.10
7104	PLUNGER, reel lock	.05
7105	SPRING, reel lock	.05
7106	PIN, reel lock	.05
7124	CUP, oil	.15
7226(D)	LUG, solder	.05
7262(D)	BRUSH, ventilating motor	.35
8115	WASHER, steel ½" O.D. x 9/32" I.D.	.05
8507	WINDOW, red glass	.35
8544(D)	SCREW, lamp socket clamp	.25
8607(D)	SCREW, panel thumb 8/32 x ½"	.20
8737	WASHER, tension	.15
8878	FRAME, magazine glass	.25
9056	SOCKET, framing lamp	.75
9057	SWITCH, lamp or motor	2.50
9156	WASHER, fiber ¾" O.D. x 5/16" I.D.	.10
9175	SCREW, 8-32 x 3/16"	.10
10051	SLEEVE, sound lens	1.75
10053	SPRING, sound lens	.25
10055	PIN, guide	.05
10104	SCREW, knurled cover	.50
10119	MOUNT, filter bearing	12.00
10500	MOUNT, exciter lamp and sound lens, SUB-ASSEMBLY	41.25
10501	SOCKET, exciter lamp, KIT-ASSEMBLY	2.20
10502	SCREW, focusing, SUB-ASSEMBLY	1.35
10503	SHAFT, take-up reel, SUB-ASSEMBLY	4.50
10504	COLLAR, feed-shaft, SUB-ASSEMBLY	3.00
10506	SPROCKET, mechanism chain, SUB-ASSEMBLY	14.00
10507	FILTER, sound, SUB-ASSEMBLY	42.50
10510(C)	CASE, upper	4.85
10511(C)	DOOR, upper rear	6.00
10512(C)	DOOR, front	6.00
10513(C)	DOOR, stationary	5.00
10514(C)	GUARD, bottom fire	.25
10515	SCREW, binder head 10-32 x ⅜"	.05
10516	SCREW, oval head 10-32 x 1⅝"	.05
10517	BUMPER, rubber	.05
10518(C)	GUARD, bottom fire	.25
10519(C)	HANDLE, case, ASSEMBLY	1.00
10520(C)	CASE, magazine	24.00
10521(C)	DOOR, front	6.00
10522(C)	DOOR, rear projector	6.00
10523	SCREW, binder head 8-32 x ⅜"	.05
10525	MOVEMENT, intermittent and framer head SUB-ASSEMBLY	123.00
10526(D)	CONDENSER KIT-ASSEMBLY	6.20
10527(D)	RESISTOR KIT-ASSEMBLY	5.70
10528(D)	TUBE KIT-ASSEMBLY	12.15
10529(D)	POTENTIOMETER KIT-ASSEMBLY	2.25
10530	CASE, intermittent SUB-ASSEMBLY	16.90
10531	STAR and sprocket SUB-ASSEMBLY	18.50
10533	FLYWHEEL and sprocket SUB-ASSEMBLY	13.50
10534	NUT, flywheel lock, SUB-ASSEMBLY	5.55
10535	BEARING, oil cup, SUB-ASSEMBLY	.40
10537	ARM, intermittent and cover SUB-ASSEMBLY	31.50
10538	SCREW, binder head 8-32 x 9/16"	.15
10539	SCREW, fillister head 8-32 x ½"	.15
10540	CLAMP, retaining	.30
10541	COVER, case and bearing arm	15.50
10542	BEARING, inner star	3.00
10543	BEARING, outer star	3.60
10544	GASKET, oil glass	.15
10545	GLASS, oil	.15
10546	NUT, oil glass	.30
10547	PIN, pivot	.15
10548	SCREW, fillister head 3-48 x 3/16"	.15
10549	SCREW, fillister head 3-48 x 3/16"	.15
10550	STRIPPER, film	.60
10551	BEARING, flywheel shaft	5.40
10552	BEARING, cam shaft	6.30
10555	DEFLECTOR, oil	.55
10556	GASKET, oil	.15
10559	FLYWHEEL	4.90
10560	WASHER, oil retaining	.15
10562	SCREW, lock nut	.15
10569	SCREW, set 10-32 x 3/16"	.15
10570	COLLAR, star shaft	.90
10571	PIN, intermittent sprocket	.15
10572	SCREW, collar set	.15
10573	STAR and shaft	11.00
10620	LEAD, wire 26½"	.15
10621(D)	WIRE and lugs, lamp socket	.25
10686	PLATE, mechanism, KIT-ASSEMBLY	32.50
10701	CASTING, aperture	20.70

MINIMUM NET ORDER $1.00

Part No.	Description	Price
10707(C)	BRACKET, amplifier mounting	4.00
10720(C)	PANEL, field supply front	1.30
10721(C)	BRACKET, amplifier chassis	3.90
10722(C)	BRACKET, monitor mounting, right, ASSEMBLY	.75
10733(D)	PLATE, #1, inner baffle	.35
10734(D)	PLATE, #2, center baffle	.35
10735(D)	PLATE, #3, outer baffle	.35
10736(C)	CASTING, main changeover	22.50
10737(C)	SHUTTER, changeover	6.70
10738(C)	COIL, (with male connector	22.50
10739(C)	CABLE, four wire, with female connector	7.50
10740(C)	ARMATURE, with flexible shaft and knob	10.15
10741(C)	KNOB, armature	1.15
10742(C)	SECTION, steel armature	3.00
10743(C)	SECTION, brass armature	3.75
10744(C)	SHAFT, flxeible, with connector	3.75
10745(C)	SCREW, armature speed adjusting	.15
10746(C)	NUT, armature speed adjusting screw	.10
10747(C)	TUBE, flexible shaft	3.00
10748(C)	CLAMP, flexible shaft tube	.40
10749(C)	BALL, armature sound switch	.40
10750(C)	BOX, sound switch	6.00
10751(C)	HOUSING, foot switch	7.50
10752(C)	TREADLE, foot switch box	6.70
10753(C)	PIN, treadle hinge	1.50
10754(C)	PIN, treadle hinge pin, cotter	.35
10755(C)	PLUNGER, treadle return	2.00
10756(C)	SPRING, treadle return plunger	.75
10757(C)	BLOCK, two wire terminal	2.00
10758(C)	INSULATOR, terminal fiber	.55
10759(C)	NUT, treadle adjusting	.40
10760(C)	BOLT, treadle adjusting nut	.55
10779	GEAR-CAM, flywheel-intermittent KIT-ASSEMBLY	16.20
10780	FRAMER SUB-ASSEMBLY	45.00
10782	PLATE, gear rack mounting	.40
10783	BAR, chain idler slide	.65
10784	SLIDE, chain idler	1.50
10785	STUD, chain idler bearing	.25
10786	SUPPORT, framer gear rack shaft	6.50
10793	MOVEMENT, intermittent framer ASSEMBLY	165.00
10794	MOTOR, 3450 R.P.M. 115 volt 60 cycle 1/8 h.p.	45.50
10795	HOUSING, intermittent SUB-ASSEMBLY	15.60
10796	GEAR, segmental framing SUB-ASSEMBLY	3.20
10797	CASE, intermittent UNIT ASSEMBLY	22.50
10798	GEAR, shutter KIT ASSEMBLY	12.25
10801(D)	SCREW, button head, 8-32 x 1/4"	.05
10802(D)	BOLT, round head, 2 1/2"	.05
10803(D)	NUT, elastic stop, 10-24	.05
10804(D)	WASHER, resistor centering	.05
10844(C)	BRACKET, monitor mounting, left, ASSEMBLY	.75
10900(D)	REFLECTOR ASSEMBLY	15.00

Part No.	Description	Price
10901(D)	FRAME, condenser	5.70
10902(D)	RING, reflector	2.60
10903(D)	BRACKET, door latch	1.25
10904(D)	MAGAZINE, feed, SUB-ASSEMBLY	67.00
10905(D)	MAGAZINE, feed, ASSEMBLY	83.00
10906(D)	CATCH, door latch	.85
10907(D)	DOOR, front	6.00
10908(D)	DOOR, rear	6.00
10909(D)	CASE, upper	4.85
10910(D)	CASE, upper ASSEMBLY	150.00
10911(D)	DOOR, stationary	5.00
10912(D)	GUARD, bottom fire	.25
10913(D)	GUARD, top fire	.25
10914(D)	CASE, magazine	24.00
10915(D)	CASE, lower, ASSEMBLY	150.00
10916(D)	DOOR, front	6.00
10917(D)	DOOR, rear	6.00
10918(D)	HANDLE, case, ASSEMBLY	1.00
10919(D)	BRACKET, tilting, ASSEMBLY	4.85
10920(D)	BRACKET, tilting	2.00
10921(D)	COVER, metal	3.50
10923(D)	BASE, lamphouse	1.35
10924(D)	TOP, lamphouse	1.00
10925(D)	COVER, lamphouse ASSEMBLY	2.50
10926(D)	VALVE, lower fire, ASSEMBLY	8.50
10927(D)	CASTING, lower fire roller	2.25
10929(D)	COVER, photo-cell	1.25
10931	BRACKET, sprocket idler KIT ASSEMBLY	2.00
10932	SHAFT-BEARING, feed sprocket KIT ASSEMBLY	12.00
10933	SHAFT-BEARING, sound sprocket KIT ASSEMBLY	12.60
10934(D)	PLATE, DeVry data name	.35
10940(C)	BOX-END, sound switch	1.25
10941(C)	BRACKET, sound switch mounting	3.15
10942(C)	SWIVEL, shutter (with set screw)	1.90
10943(C)	RETURN, flat spring	.85
10944(C)	INSULATION, switch fiber	.15
10945(C)	SCREW, terminal block mounting	.15
10946(C)	SCREW, coil mounting	.10
10947(C)	SCREW, flexible shaft tube clamp	.10
10948(C)	HOLDER, flexible shaft tube	1.25
10949(C)	SCREW, sound switch box	.10
10952(C)	SCREW, sound switch box mounting	.10
10953(C)	SCREW, shutter swivel set	.15
10954(C)	SCREW, name plate mounting	.10
10956(C)	SCREW, sound switch bracket swivel	
10957(C)	INSULATOR, sound switch fiber	.25
10958(C)	LEAD, sound switch (red) only	.45
10959(C)	CONDUIT	.95
10965	WASHER, inner cut lock	.05
10981	GEAR-MECHANISM, CA. & SLI. idler ASSEMBLY	21.00

MINIMUM NET ORDER $1.00

Since 1913 an outstanding name in the field of Visual Education

DeVRY

MOTION PICTURE CAMERAS AND PROJECTORS

5-TIME WINNER

DeVRY ALONE has Earned FIVE Consecutive Army-Navy "E's" for Excellence in the Production of Motion Picture Sound Equipment.